MOORE TOP-ACTION PENCIL

Follow these simple instructions for Best Results

Hold in \rightarrow vertical position

Press top ->



A new point \longrightarrow appears

IT'S EASY!

When a new supply of lead is needed, remove top by pulling straight off, remove eraser cap, and place 24 pieces "fine" lead in storage chamber. Replace eraser in cap.