

TO INSTALL AN INK CARTRIDGE:

Remove cap and unscrew pen barrel. Insert the ink cartridge into the lower section with arrow pointing forward as shown. Replace the barrel and the tightening motion will puncture the cartridge inside the pen. Your hands stay completely clean. Then touch the writing point of your pen lightly on paper. This facilitates ink flow and brings ink to the writing point.

USE ONLY SUPER QUINK INK CARTRIDGES IN YOUR PEN

THE EVERSHARP PEN COMPANY $\,$ a division of $\,$ the parker pen company