HOW TO FILL YOUR

Sheaffer's BALLPOINT



To replace ballpoint unit, unscrew barrel, remove old unit, insert new unit and reassemble barrel to cap.

USE ONLY SHEAFFER'S





Turn cap clockwise until metai rod appears at point. Then turn back completely . . insert lead . . . press lead gently against hard surface to engage clutching mechanism.

ALWAYS USE SHEAFFER'S FINELINE LEADS AND ERASERS

GUARANTEE

For a period of one year from date of purchase, Sheaffer guarantees to replace without charge, except for transportation and insurance, any parts which upon factory inspection are found to be defective.

W-388 10-55

PRINTED IN U.S.A.

W. A. SHEAFFER PEN COMPANY

Fort Madison, Iowa, U.S.A. In Australia: Melbourne In Canada: Goderich, Ontario In Great Britain: London

HOW TO OPERATE YOUR NEW

SNORKEL PEN

Because Sheaffer's Snorkel Pen is so new and different, it is important that you *read these brief directions carefully before filling*. By following them you'll enjoy the trouble-free service and writing smoothness that is traditionally Sheaffer's.



This is another advanced-design pen by Sheaffer. It is a new pen development, and should be filled as shown in the TIPdip directions to enjoy the full benefit of its convenience.

INSTRUCTIONS

FIVE EASY STEPS FOR PROPER FILLING . SHEAFFER'S SNORKEL PEN



 Unscrew plunger knob...using gentle forward pressure on knob while turning. UNSCREW UNTLL DEFINITE "CLICK" IS FELT. Filling tube is now fully extended.

IMPORTANT

Your Snorkel pen is precision made. It is not necessary to dismantle your pen in ordinary usage and you may damage it if you attempt to do so.

Keep the barrel and point section (see below) screwed tightly together.



FOR BEST RESULTS



Top-well bottle makes filling easy ... uses all of the ink. SKRIP cleans and protects the inner parts of the pen.



 Hold filling tube over ink bottle and pull plunger out as far as it will go.



 Immerse only the filling tube in ink. It is not necessary to "dunk" the pen point. However, on FILLING of new pen the first time, the tip of point should be moistened in ink.



 Now push plunger all the way down just once. Keep the tube in the ink a few seconds as your Snorkel Pen "drinks the ink."



THREE EASY STEPS FOR PROPER FILLING



Unscrew plunger knob of

pen . . . pull out plunger to

full length.

Immerse only the tip of point In Ink to cover heart-shaped hole in pen point . . . as shown.



SHEAFFER'S TIP-DIP PEN

3

Push plunger all the way down just once. Wait . . . count ten slowly as pen fills full. Screw plunger knob back on barrel and your pen is ready to write. Note that Sheaffer pens fill on the down stroke.

TIP-DIP KEEPS POINT AND BARREL CLEAN