HOW TO FILL YOUR PARKER 45 PEN

Remove barrel and insert the filler unit into pen, pushing gently.

Holding gray section of the filler with one hand, turn red section counter-clockwise until plunger is lowered. Lower pen point into ink, turn red section clockwise five times. The pen is now filled. Remove any excess ink from point with absorbent tissue and replace barrel. After filling, the unit is positioned securely by the tightening motion as you replace the barrel.



Long Term Care of Your Parker 45

Your Parker 45 is a precision writing instrument, crafted within exacting tolerances. With simple, reasonable care, your Parker 45 will give you years of reasonable service.

Writing Point—should your pen point become damaged accidentally, it is easily and quickly replaced.

SUPER QUINK Ink—in the familiar 2-ounce bottle or in throw-away cartridges—is recommended for use in the Parker 45 pen.

THE PARKER PEN COMPANY JANESVILLE, WISCONSIN, U.S.A.

NO. 9076E/PRINTED IN U.S.A./12-61

First in quality

Inserting A Reserve Ink Cartridge in Your Parker 45



Unscrew barrel and remove permanent filler unit.



Insert new ink cartridge with arrow pointing forward as shown. Replace barrel and the tightening motion will puncture the cartridge inside the pen. Your hands stay completely clean. . . . and Now, in Just a Few Seconds, You're Ready to Write Again!



After filling, rest the point of your pen lightly on paper for a few seconds. This facilitates ink flow and brings ink to the writing point.

SUPER QUINK Ink is Best for Your Parker 45 Pen

Parker's exclusive ink formula, SUPER QUINK, keeps your pen writing like new, aids instant starting. Choose from six brilliant permanent colours and Washable Royal Blue.



How to Install New Lead in Your Parker 45 Mechanical Pencil

Turn the cap clockwise until a clicking sound is heard to be sure all particles of old lead are ejected. Then turn the cap counterclockwise until a slight resistance is felt.

Insert new lead through hole in tip. Gently push lead all the way into the tip. Turn cap clockwise until lead projects about 1/8th inch. Press point on table top or pad of paper to seat the new lead securely.

Please Note: The reserve chamber in the barrel holds 6 spare double-length leads. Do not try to force more into the chamber.